

**Product:** Tekloom® - High Performance Fused Textile

**Content:** Polyester 85%-88%, Tekloom® TPE 12-15%

## GENERAL MAINTENANCE

While Tekloom® is inherently stain resistant, it is important to keep it clean at all times to maintain the original look and feel. Spot cleaning with a clean, soft towel with clean water will remove most of the everyday stains.

Cleaning Code: WS (Acid, Alcohol, Bleach (1:10), Ozone, Peroxide, Phenolic, Quat, UV-C Light -Based)

## DISINFECTION

This product can be disinfected with a 1:10 bleach dilution of bleach/water. Allow the mixture to linger for the time specified by the Center for Disease Control and Prevention.

Rinse all cleaning agents thoroughly with water and wipe with a soft cloth.

*Residue left by cleaning agents will degrade and shorten the life and/or affect the product's appearance if not removed.*

## APPROVED DISINFECTANT CLEANERS

Tekloom is cleanable with all Eight Families of Disinfectant Cleaners: Acid, Alcohol, Bleach, Ozone, Peroxide, Phenolic, Quat, UV-C Light -Based. This list represents some of the most common options available and is not intended to be comprehensive.

- 3M C Diff Solution Tablets
- 3M Neutral Quat Disinfectant Cleaner Concentrate 23H
- 3M Neutral Quat Disinfectant Cleaner Concentrate 23L
- 3M HB Quat Disinfectant 25L
- Amphyl
- Cavi Wipes XL
- Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes
- Ecolab Neutral Disinfectant Cleaner
- Oxivir 1
- Oxivir Plus
- Oxivir Tb Wipes
- Oxycide
- Perisept
- Sani-Cloth AF3 Germicidal Disposable Wipes
- Steris (Coverage Spray HB Plus)
- Stride Fragrance Free SC Neutral Cleaner
- Virex 256
- Virex Plus
- Wexcide 128